


NOTE: Nose gear bearing block and steering used to actuate retracts.



NOTE: A spring retract assist may be necessary to insure proper retraction of gear. Dotted line denotes areas to be cut away for spring clearance

