

ASSEMBLY

JOIN THIS SECTION WITH TWO
PIECES OF TUBING, WELD WITH
ZINC AND SOLDER.

LOWER YOKE
ASSEMBLY

W-9

W-10

W-11

NOTE:

Turn plans over to construct oppo-
site wing. Rubbing plans with a
light oil will make them more trans-
parent.

W-28

Royal Pinned Hinge